

E-Transit Custom

Kuinka latauskaapeli irrotetaan

1. Avaa auton lukitus sovelluksesta.
2. Vapauta latauskaapelin lukitus latausluukussa sijaitsevaa vapautuspainiketta painamalla. Irroita latauskaapeli autosta ja latausasemasta, sulje latausluukku.
3. Sijoita auton mukana kulkeva latauskaapeli auton takatavaratilaan.

Kuinka autolla lähdetään liikkeelle

1. Istu autoon ja paina jarrupoljin pohjaan.
2. Kytke turvavyö.
3. Käynnistä auto painamalla käynnistuspainiketta.
4. Paina vaihteenvälitsin **Drive (D)** – asentoon (ajovaihde) tai nosta vaihteenvälitsin **Reverse (R)** – asentoon (peruutusvaihde).
5. Nosta jalka jarrupolkimelta ja paina kaasupoljinta vähän kerrallaan. Käsijarru vapautuu automaattisesti liikkeelle lähdettäessä.

Kuinka ajo lopetetaan

1. Pidä jarrupoljin pohjassa.
2. Paina vaihteenvälitsimen vieressä olevaa **P** painiketta, jolloin pysäköintivaihde **Park (P)** kytkeytyy. Käsijarru kytkeytyy automaattisesti.
3. Sammuta auto painamalla käynnistuspainiketta.
4. Poistu autosta ja kytke latauskaapeli. Auton latausluukku aukeaa painamalla latausluukun vasemmasta reunasta.

5. Lukitse auto sovelluksesta.

Kuinka auton vaihteita käytetään

Auton vaihdevalitsin sijaitsee ohjauspalkissa ohjauspyörän oikealla puolella ”viiksessä”.

Drive (D) – ajovaihde

Paina vaihteenvälitsintä alaspäin kunnes vaihde kytkeytyy. Voit valita ajovaihteen kun auto on paikallaan.

Park (P) – pysäköintivaihde

Kun auto on paikallaan, paina vaihdevalitsimen päässä olevaa **P-painiketta**, jolloin pysäköintivaihde **Park (P)** kytkeytyy. Pysäköintijarru kytkeytyy automaattisesti.

Reverse (R) – peruutusvaihde

Nosta vaihteenvälitsintä ylöspäin kunnes vaihde kytkeytyy. Voit valita peruutusvaihteen, kun auto on pysäytetty.

Neutral (N) – vapaa

Paina vaihteenvälitsintä hieman alas tai nosta hieman ylös, riippuen siitä onko kytkettynä **P**, **R** tai **D**. Vapaan ollessa kytkettynä, auto kulkee vapaasti mikäli et paina jarrupoljinta.

Huom!

Auton vaihdevalitsin ei jää fyysisesti valinnan mukaiseen kohtaan, vaan palautuu aina keskelle. Tämä kuuluu asiaan.

Ongelmatilanteissa:

sharing@aimopark.fi | 020 7812 490

E-Transit Custom

How to disconnect the charging cable

1. Unlock the car using the app.
2. Release the charging cable by pressing the release button that is at the charging port. Disconnect the charging cable from the car and the charging station, then close the charging port.
3. Place the charging cable provided with the car into the car.

How to start driving the car

1. Sit in the car and press the brake pedal firmly.
2. Fasten your seatbelt.
3. Start the car by pressing the Start- button.
4. Push the gear selector down to the **Drive (D)** position for forward driving or lift up to the **Reverse (R)** position for reversing.
5. Lift your foot off the brake pedal and gently press the accelerator pedal. The parking brake will release automatically as the car starts moving.

How to stop driving

1. Keep the brake pedal pressed.
2. Press the P button located on the gear selector to engage the parking gear **Park (P)**. The parking brake will engage automatically.
3. Turn off the car by pressing the Start- button.
4. Exit the car and connect the charging cable. The charging port opens by pushing the left side of the charging port.

5. Lock the car using the app.

How to use the car's gear selector

The gear selector is located on the right side of the steering wheel and operates by pushing down or lifting up.

Drive (D) - driving gear

Push the gear selector down until the gear engages. You can select the driving gear while the car is stationary.

Park (P) - parking gear

When the car is stationary, press the P button on the gear selector to engage the parking gear **Park (P)**. The parking brake will engage automatically.

Reverse (R) - reverse gear

Lift the gear selector up until the gear engages. You can select reverse gear when the car is stopped.

Neutral (N) - neutral gear

Push the gear selector slightly down or lift it slightly upward, depending on whether P, R, or D is engaged. In Neutral, the car will roll freely unless the brake pedal is pressed.

Please note!

The gear selector does not stay in the physical position corresponding to the gear selection but always returns to the center position. This is intentional.

Problem situations:

sharing@aimopark.fi | +358 (0)20 7812 490