

Hyundai Kona

Kuinka latauskaapeli irrotetaan

1. Avaa auton lukitus sovelluksesta.
2. Irrota latauskaapeli autosta ja latausasemasta 15 sekunnin kuluessa ovien aukeamisesta, muuten kaapeli lukittuu uudestaan. Jos näin käy, avaa auton lukitus uudestaan.
3. Sulje latausluukku ja siijoita auton mukana kulkeva latauskaapeli auton takatavaratilaan.

Kuinka autolla lähdetään liikkeelle

1. Istu autoon ja paina jarrupoljin pohjaan.
2. Kytke turvavyö.
3. Käynnistä auto painamalla **START/STOP-kytkintä**, joka sijaitsee ratin oikealla puolella.
4. Pyöritä vaihteenvälitsin **Drive (D)** -asentoon (ajovaihde) tai **Reverse (R)** -asentoon (peruutusvaihte). Voit tarkistaa valinnan vaihteenvälitsimen luona olevista merkkivaloista.
5. Nosta jalka jarrupolkimelta ja paina kaasupoljinta vähän kerrallaan. Käsijarru vapautuu automaattisesti liikkeelle lähdetäessä.

Kuinka ajo lopetetaan

1. Pidä jarrupoljinta pohjassa.
2. Paina vaihteenvälitsimen päällä olevaa **P** painiketta, jolloin pysäköintivaihte **Park (P)** kytkeytyy. Käsijarru kytkeytyy automaattisesti.
3. Nosta jalka jarrupolkimelta.
4. Sammuta auto painamalla **START/STOP** painiketta ratin oikealla puolella.

5. Poistu autosta ja kytke latauskaapeli.
6. Lukitse auto sovelluksesta.

Kuinka auton vaihteita käytetään

Auton vaihdevalitsin sijaitsee ohjauspyörän oikealla puolella.

Drive (D) - ajovaihde

Pyöritä vaihteenvälitsinta eteenpäin. Voit valita ajovaihteen, kun auto on paikallaan.

Park (P) - pysäköintivaihte

Kun auto on paikallaan, paina vaihteenvälitsimen päällä olevaa **P-painiketta**, jolloin pysäköintivaihte **Park (P)** kytkeytyy. Pysäköintijarru kytkeytyy automaattisesti.

Reverse (R) - peruutusvaihte

Pyöritä vaihteenvälitsinta vasemmalle. Voit valita peruutusvaihteen, kun auto on pysäytetty.

Neutral (N) - vapaa

Pyöritä vaihteenvälitsinta eteenpäin tai itseäsi päin, kuitenkin vain sen verran, ettei vaihte **D** tai **R** kytkeydy. Auto kulkee vapaasti, mikäli et paina jarrupoljinta.

Huom!

Auton vaihdevalitsin ei jää fyysisesti valinnan mukaiseen kohtaan, vaan palautuu aina keskelle. Tämä kuuluu asiaan.

Ongelmatilanteissa:

sharing@aimopark.fi | 020 7812 490

aimo
share

Hyundai Kona

How to disconnect the charging cable

1. Use the app to unlock the car.
2. Detach the charging cable from the car and charging station within 15 seconds of opening the doors, otherwise the cable will lock again. If this happens, unlock the car again.
3. Close the charger port cover and place the charging cable that comes with the car in the boot.

How to start driving

1. Sit in the car and press the brake pedal firmly.
2. Fasten your seatbelt.
3. Start the car by pressing the **START/STOP button** to the right of the steering wheel.
4. Turn the gear selector to the **Drive (D)** position or **Reverse (R)** position. You can check the selection based on the indicator lights by the gear selector.
5. Take your foot off the brake pedal and begin pressing the gas pedal down gradually. The parking brake is released automatically when starting to move.

How to stop driving

1. Hold the brake pedal down.
2. Press the P button at the end of the gear selector to shift to the parking gear **Park (P)**. The parking brake is engaged automatically.
3. Take your foot off the brake pedal.
4. Switch off the car by pressing the **START/STOP button** to the right of the steering wheel.

5. Exit the car and connect the charging cable.
6. Use the app to lock the car.

How to use the gears of the car

The gear selector is located on the right-hand side of the steering wheel.

Drive (D) - driving gear

Turn the gear selector forwards. You can select the gear when the car is stationary.

Park (P) - parking gear

When the car is stationary, press the **P button** at the end of the gear selector to engage the parking gear **Park (P)**. The parking brake is engaged automatically.

Reverse (R) - reverse gear

Turn the gear selector towards you. You can select the reverse gear when the car is not moving.

Neutral (N) - neutral gear

Turn the gear selector forwards or backwards, but only enough to avoid engaging the D or R gear. The car will now roll freely if you do not press the brake pedal.

Please note!

The car's gear selector will not physically remain in the position of the selected gear. Instead, it will always return to the centre. This is how the selector is intended to function.

Problem situations:

sharing@aimopark.fi | +358 (0)20 7812 490